

Guide to Mercedes E-Class air suspension compressor removal

Removing the Wabco air suspension compressor: This is a guide for the Mercedes E-Class 2002-2009, Some models may differ slightly.

It is important to be aware of all necessary safety measures while working on your air suspension system. This includes proper lifting and immobilizing of the vehicle if required and isolation of any stored energy to prevent personal injury or property damage.




Basic steps to remove the compressor

1. The Compressor is located on the vehicles LH side behind the Front Bumper




2. Remove engine compartment panelling. (Figure Below)



3. Unscrew pressure line connection and air filter line from the compressor unit. (Figure below)



4. Disconnect the two (2) electrical connectors for the compressor unit. (Figure Below)



5. Unscrew the three nuts (arrows) and remove the compressor unit.

